


# **Foot-switch**

# Series F1

### Description F1-SU1ZDA1Z UN

Article number 6161000288



Electrical data		
Rated insulation voltage	U <sub>i</sub>	400 V AC
Conv. thermal current	$I_{the}$	10 A
Rated operational voltage	$U_e$	240 V
Utilization category		AC-15, U <sub>e</sub> / I <sub>e</sub> 240 V / 3 A
Direct opening action	$\Theta$	acc. to IEC/EN 60947-5-1, Annex K (pedal stop)
Short-circuit protective device		Fuse 2 A gG
Protection class		I

## **Technical Data**



Mechanical Data			
Enclosure	AL, die-cast		
Protective guard (Accident protection cover UN)	AL, die-cast Colour: yellow-orange (RAL 2000)		
Actuator	Foot lever (PA)		
Ambient air temperature	-30 ° C +80 ° C		
Contact type	2 N.C. / 2 N.O. (Zb)		
Operating force	≈ 10 N (pedal centre)		
Pressure point	≤ 460 N ± 10 % (pedal centre)		
Mechanical life without actuating the pressure point with actuating the pressure point	10 x 10 <sup>6</sup> switching cycles 1 x 10 <sup>6</sup> switching cycles		
Switching frequency	≤ 50/min		
Assembly	2 x M8		
Connection	screw connections (M3,5)		
Number of connections	8		
Conductor cross-sections	Solid: 0,5 1,5 mm <sup>2</sup> Litz wire with ferrules: 0,5 1,5 mm <sup>2</sup>		
Cable entrance	1 x M20x1,5		
Protection ground	2 x M4		
Weight including protective guard	≈ 1,523 kg		
Protection type	IP 65 acc. to IEC/EN 60529		

Standards	
DIN EN 60947-5-1	

EU Conformity	
acc. to direc	tive 2014/35/EU (Low-Voltage-Directive)

#### **Notes**

Three-stage safety switch with latching

The safety contact element consists of two adjoining switching systems which guarantee a normal work flow and in the case of an emergency the safety function "emergency-stop".

- 1. The normal work flow is initiated by pressing down the pedal to the pressure point, where by the contacts 13 14 and 43 44 are closed in succession.
- 2. In the case of an emergency, the pedal is pressed as far as it will go beyond the pressure point. The NC contacts 35 36 are force-opened and thereby the work process stops. At the same time, the automatic latching function is activated and holds all contacts in "emergency-stop position". This reliably prevents uncontrolled restart of the machine or moving parts.

  Safety for man and machine!
- 3. Only after the release of the pushbuttons on the side of the enclosure, the contacts will be released again and can be closed again by pressing the pedal beyond resistance of the pressure point.

The working process continues.

## Notes

The degree of protection (IP code) specified applies only to a properly closed accident protection cover and in connection with the appropriate cable glands with the appropriate cable.

BERNSTEIN AG. Hans-Bernstein-Straße 1.32457 Porta Westfalica. www.bernstein.eu